

EZ CLEAN PLUS

Wipes for lens cleaning

Designed for cleaning of high-power CO₂ laser lenses



EZClean⁺

REUSABLE WIPES FOR LENS CLEANING

Ophir® **EZ Clean™ Plus** are innovative re-usable wipes, composed of special non-scratch fabric, for routine and deep cleaning of the optical laser lenses for maximizing performance of the optical system.

Designed for cleaning and safely handling sensitive optical components for maintenance. Extremely durable and reusable.

Ophir® EZ-Clean™ Plus package includes 24 ready-to-use wipes, individually wrapped in resealable package. A few seconds of cleaning prolong lens' life-time and significantly shortens down-time for laser systems.



LENS CLEANING INSTRUCTIONS

Routine Lens Cleaning Instructions Using EZ Clean™ Plus wipes



Step 1:
Open pack



Step 2:
Take out the folded EZ Clean™ Plus



Step 3:
Using an “S” motion, wipe from top to bottom



Step 4:
Turn the lens upside down



Step 5:
Turn the EZ Clean™ Plus wipe to the other side



Step 6:
Using an “S” motion, wipe from top to bottom



Step 7:
Store the wipe back into the zipper bag



To maximize effectiveness:

- Wear finger cots or rubber gloves
- Use Ophir Lens Holder
- Clean working environment

